















- Clamp rear jaws to lower edge of top, allowing space for leg.
- Attach front jaw to rear jaws with double-sided tape.
- Layout and drill holes through front and rear at same time.