


0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

One Square = One Inch



Printing Instructions

1. Your computer must have the newest version of Adobe Reader to print this pattern. It's a free download for both Mac and PC computers at get.adobe.com.
2. Open the PDF in Adobe Reader and click on the toolbar's print icon to open the "Print" window.
3. Select "All" under "Pages to Print."
4. Select "Poster" under "Page Sizing and Handling."
5. Set the Tile Scale window to 100%.
6. Set the Overlap to 1.25".
7. Click "Print." The pattern will print on successive sheets of 8-1/2" x 11" paper.

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40